# IPad mini1 3G to WiFi

R1204 can be removed directly with tweezers or soldering iron (if the resistor is removed, it can't be turned on and the machine can be swiped). If some versions don't have r1205, you need to short-circuit it, open the computer, connect to iTunes, call WiFi version data, and the machine can be swiped




