iPad4 3G to WiFi

R1204 can be removed directly with tweezers or soldering iron (after removing the resistance, do not start the machine, brush the machine) Open the computer, connect to iTunes, call the WiFi data, and then swipe the computer

