[machine model]: ipad4

[Fault phenomenon]: no display, no response at boot

The machine is turned on without display, no response, no connection



[Maintenance process]:

Disassemble, the Adjustable Power supply on the board is turned on, the current is up to 90 mA, and the current is up here, but the SDRAM, this machine has 2 SDRAM, I am the first to remove the left side, re-do SDRAM.





Luck is better, after finishing the SDRAM on the left, the power-on current jumps normally.The repair is over!


0564 0430
FLUKE
OL




iPad 4
开机无显示、无反应
19:30
4月16日 星期日
滑动来解锁