Fault model: iPad air2

Symptom: No Power ON

Received a customer's machine Air2 normally use No Power ON, get the machine and found that it is really unable to open the machine, directly remove the motherboard and find the motherboard has leakage of electricity(battery abnormal consumption) 800MA, after testing, it is found that the WIFI chip is damaged.



The Colophony (Solder) on the Colophony (Solder) WIFI chip has been obviously melted. The wifi chip is directly removed and the motherboard is not leakage of electricity(battery abnormal consumption).



Clean up the solder pad



`

Install a good wifi chip



Install the wifi chip machine, the normal boot wifi function is normal, the repair is over.